



# Positioning holes in the Positioner.

Example applications:

<b>6</b>	Center of furniture board 12 mm	<b>28</b>	Front panel attachments
<b>6,5</b>	Flippers	<b>32</b>	System 32
<b>8</b>	PK2	<b>34</b>	Eccentric connectors
<b>9</b>	Center of furniture board 18 mm	<b>37</b>	System 32 (first hole from the edge)
<b>9,5</b>	Sides of the body	<b>P</b>	Straight guides
<b>17</b>	Blum eccentric connectors	<b>H</b>	37 mm from the HDF groove
<b>20</b>	Target J10	<b>CHAMFER HOLES</b>	Lamello Cabineo
<b>22</b>	Hinge cups fi 35 mm	<b>OTHER</b>	Technological (used in production)
<b>24</b>	Eccentric connectors		

The dimensions presented above can be achieved by placing neutral or spacing pins in individual holes.